

CHANNEL	STANDARD
1	PAN
2	PAN FINE
3	TILT
4	TILT FINE
5	TILT ROTATION
6	FUNCTION

Channel Mode Standard	DMX Value	Function
1		PAN
	000 – 255	Pan CCW movement/positioning from 0° to 540° (default setting)
2		PAN FINE
	000 – 255	Fine Pan positioning
3		TILT
	000 – 255	Tilt CCW movement/positioning from 0° to 360° (default setting)
4		TILT FINE
	000 – 255	Fine Tilt positioning
5		TILT ROTATION
	000	Direct Tilt positioning
	001 – 127	Tilt CCW rotation from Fast to Slow
	128	Stop Tilt rotation
	129 – 255	Tilt CW rotation from Slow to Fast
6		FUNCTION
	000 – 011	Unused range
	012 – 024	Fast Pan/Tilt speed
	025 – 037	Normal Pan/Tilt speed
	038 – 042	Reset
	043 – 255	Free
		The functions are activated/selected passing through the unused levels range and staying in the necessary range for 5 seconds