Axcor 300-400 series

Maintenance Table
03/2019

Adjust | **Check** | **Clean** | **Lubricate** | **Replace** | **Update**

Parts	Every 300 hrs or whenever possible	750 hrs	1500 hrs	2250 hrs	3000 hrs	3750 hrs	4500 hrs	5250 hrs	6000 hrs	6750 hrs	7500 hrs	8250 hrs	9000 hrs	9750 hrs	10500 hrs	11250 hrs	12000 hrs
Fans	Clean, Check				Replace				Replace				Replace				Replace
Color Filters	Clean, Check																
Glass gobos	Clean, Check																
Prism/Frost	Clean, Check																
Lenses	Clean, Check																
Eletronic Boards	Clean, Check																
PSU/Driver/Ballast	Clean, Check																
Pan/Tilt Belts	Check				Replace				Replace				Replace				Replace
Effects Belts	Check								Replace								Replace
CMY Belts	Check				Replace				Replace				Replace				Replace
Rails	Lubricate																
Iris	Check				Replace				Replace				Replace				Replace
Battery	Check				Replace				Replace				Replace				Replace
Gobo Bearings	Check				Replace				Replace				Replace				Replace
Head/Yoke/Base	Clean, Check																
Firmware	Update																